Remington Arms Company, Inc. 870 Remington Drive PO Box 700 Madison, NC 27025-0700 (336) 548-8700 800-243-9700

REMINGTON

Arms Company, Inc.

SPORTSMAN 58 AUTOLOADING SHOTGUN

- Shooting Safety Commandments
- Information
- Instructions for Operation & Care of Shotgun
- Components Parts Listing
- Value and Reference Book Listing

NOTE: We are pleased to accommodate your request for the Sportsman 58 Autoloading Shotgun information. The following documentation represents all information available on this model from the Remington Arms Co., Inc.


DO NOT MAKE CHANGES OR ALTERATIONS TO ANY PARTS OF A FIREARM. USE ONLY REMINGTON PARTS. NEVER MAKE AN ADJUSTMENT TO THE TRIGGER, OR CHANGE THE SHAPE OR SIZE OF THE SEAR, SEAR NOTCH, OR OTHER PARTS.

Ten Commandments of Shooting Safety

1. Always keep the muzzle pointed in a safe direction. 2. Firearms should be unloaded when not in use. 3. Don't rely on your gun's "safety". 4. Be sure of your target and what is beyond it. 5. Use correct ammunition. 6. If your gun fails to fire when the trigger is pulled, handle with care! 7. Always wear eye and ear protection when shooting. 8. Be sure the barrel is clear of obstructions before shooting. 9. Do not alter or modify your gun, and have guns serviced regularly.

10. Learn the mechanical and handling characteristics of the firearm


you are using.



MODEL SPT-58

Autoloading Shotgun

"Sportsman-58" with "Power-Matic" Action



3 Shot 12-16-20 Gauge

IDENTIFY COMPONENTS BY LOCA-TION AND PART NAME FROM SECTIONAL VIEW

This Model is Discontinued

SECTIONAL VIEW
ACTION CLOSED

REPLACEMENT PARTS

When ordering parts, specify model, gauge, part name and number, and the serial number of the gun. All parts, including barrel assemblies, will be shipped as ordered but, since they are made to close dimensions, the particular part may require slight adjustment or fitting to assure proper functioning of the arm.

Remington,

MODEL SPT-58

Autoloading Shotgun 3 SHOT

"DISCONTINUED NO PARTS AVAILABLE FROM REMINISTON"

12-16-20 Gauge

When ordering parts - Model No., Part No. and Part Name must be given.

Part No.	NAME OF PART	List Price	Part No.	NAME OF PART L	ist Price
25865 19355	Action Bar Assembly (includes Action Bar, Action Bar Stud, Slide Block) Action Bar Stud	. \$	23890	Barrel Assembly, D GRADE, All Gauges (Vent Rib only) (includes same as Barrel Assembly, Vent Rib, except uses Ivory Bead Front Sight)	
19365	Action Spring		1	(All Standard lengths available)	
	Action Spring Stop		23891	Barrel Assembly, F GRADE, All Gauges (Vent	5
95755	Action Spring Stop Assembly MAGNIIM		1 2007.	Rib only) (includes same as D GRADE)	} .
23/33	Action Spring Stop Assembly, MAGNUM GRADE (includes Action Spring Stop, Action Spring Stop Stud, Magazine Buffer Spring)		23892	Barrel Assembly, SD GRADE, All Gauges, (Vent Rib only) (includes same as SC GRADE)	Price on
	NOTE: Barrel Assemblies interchangeable without adjustment. Prices upon application.		23893	Barrel Assembly, SF GRADE, All Gauges, (Vent Rib only) (includes same as SC GRADE)	
21690	Barrel Assembly PIAIN 12 Ga (30 in) (in	1250	16358	Bolt Return Plunger	1
_ , _ , _	Barrel Assembly, PLAIN, 12 Ga. (30 in.) (in- cludes Barrel, Barrel Guide Ring, Barre Guide Pin, Front Sight, Magazine Cap De-	1	17676	Bolt Return Plunger Cross Pin	
	Guide Pin, Front Sight, Magazine Cap De	.	16360	Bolt Return Slide Plunger Spring	
	tent, Magazine Cap Detent Spring)		18869	Breech Bolt, 12 Ga. Use 16967	
21693	Barrel Assembly, PLAIN, 12 Ga. (28 in.)		23025	Breech Bolt, 16 Ga.	
21694	Barrel Assembly, PLAIN, 12 Ga. (26 in.)		16400	Breech Bolt, 20 Ga.	
21691	Barrel Assembly, PLAIN, 16 Ga. (28 in.)		23575	Breech Bolt Assembly, Complete, 12 Ga. (in-	
21695	Barrel Assembly, PLAIN, 16 Ga. (26 in.)			cludes Breech Bolt, Extractor, Extractor Plung-	
21692	Barrel Assembly, PLAIN, 20 Ga. (28 in.)			er, Extractor Spring, Firing Pin, Firing Pin Re- taining Pin, Firing Pin Retractor Spring,	
21696	Barrel Assembly, PLAIN, 20 Ga. (26 in.)	•	-	Locking Block Assembly). Use 25190	
22973	Barrel Assembly, MAGNUM GRADE, 12 Ga		23576	Breech Bolt Assembly, Complete, 16 Ga.	
	only, 28 in., VENT RIB (3 in. chamber) (See	- 5	23577	Breech Bolt Assembly, Complete, 20 Ga.	
00005	page SG-4)		16889		
23235	Barrel Assembly, VENT RIB, 12 Ga. (30 in.) (includes Barrel, Barrel Guide Pin, Barrel	i i g	20616	Butt Plate	
	Guide Ring, Front Sight, Front Sight Retain-	_ 4	25410	Butt Plate Screw	
	ing Pin, Magazine Cap Detent, Magazine		15714	Carrier, 12 - 16 - 20 Ga. Use 15628	
	Cap Detent Spring, Ventilated Rib)	.	23545	Carrier Assembly, 12 - 16 - 20 Ga. (includes	
23236	Barrel Assembly, VENT RIB, 12 Ga. (28 in.)	.	10040	Carrier, Carrier Dog, Carrier Dog Pin, Car-	
23237	Barrel Assembly, VENT RIB, 12 Ga. (26 in.)	.		rier Dog Washer, Carrier Release, Carrier	
23240	Barrel Assembly, VENT RIB, 16 Ga. (28 in.)			Release Pin, Carrier Release Spring). Use	
23241	Barrel Assembly, VENT RIB, 16 Ga. (26 in.)	-	15400	26875	
23245	Barrel Assembly, VENT RIB, 20 Ga. (28 in.)	.	15480	Carrier Dog	
23246	Barrel Assembly, VENT RIB, 20 Ga. (26 in.)		17416	Carrier Dog Follower	
23800	Barrel Assembly, SKEET GRADE, 12 Ga. (Vent		16966	Carrier Dog Follower Spring	
	Rib only) (26 in. only) (includes Barrel, Bar-		18781	Carrier Dog Pin	
	rel Guide Pin, Barrel Guide Ring, Front Sight (Ivory Bead), Magazine Cap Detent,		18760	Carrier Dog Washer	
	Spring, Middle Sight, Ventilated Rib)		16348 16345	Carrier Latch	
23802	Barrel Assembly, SKEET GRADE, 20 Ga. (Vent		16344	Carrier Latch Pin	
	Rib only) (26 in, only)			Carrier Latch Spring	
23238	Barrel Assembly, SKEET GRADE, COMP. 20 Ga.		17417	Carrier Pivot Tube	
	(Vent Rib only) (26 in. only) (includes Bar-	.	16347	Carrier Release	
	rel, Barrel Guide Pin, Barrel Guide Ring,		16983	Carrier Release Pin	
	Ventilated Rib, Compensator (steel), Com-		16327	Carrier Release Spring	
	pensator Bushing, Compensator Bushing		17419	Connector, Left	
	Screw, Compensator Front Sight, Middle		17551	Connector, Right	
	Sight, Full Choke Tube, Spreader Tube,		17420	Connector Pin	
20.47	Wrench)		16712	Disconnector	
23247	Barrel Assembly, SKEET GRADE, COMP. 20 Ga.) ii ii	25430	Ejector, 12 Ga. Use 25431	
02000	(Vent Rib only) (26 in, only)	4 dd	24449	Ejector, 16 Ga. Use 24446	
23800	Barrel Assembly, SC GRADE, 12 Ga. (Vent Rib only) (includes same as Skeet Grade)		24450	Ejector, 20 Ga. Use 24447	
3802			18647	Ejector Rivet	
3002	Barrel Assembly, SC GRADE, 20 Ga. (Vent Rib only)		16176	Extractor	
24060	Barrel Assembly, TB GRADE, 12 Ga. only, (Vent	i	17432	Extractor Plunger	į.
-500	Rib only) (30 in. length) (includes Barrel,		17433	Extractor Spring	
	Barrel Guide Pin, Barrel Guide Ring, Front		17436	Firing Pin	
	Sight (Ivory Bead), Magazine Cap Detent,	1 1	18623	Firing Pin Retaining Pin	
	Magazine Cap Detent Spring, Middle Sight,		17437	Firing Pin Retractor Spring	
4041	Ventilated Rib)		16332	Follower Latch (12 Ga. only)	;
4061	Barrel Assembly, TB GRADE, 12 Ga. only (Vent Rib only) (28 in. length)	. J	16303 16333	Follower Latch Pin (12 Ga. only)	
	BULLIOUVI VO III IMUUIDI	-	10333	Follower Latch Spring (12 Ga. only)	

Remington,

MODEL SPT-58

Autoloading Shotgun 3 SHOT

12-16-20 Gauge



PRICE LIST

When ordering parts — Model No., Part No. and Part Name must be given.

Part No.	NAME OF PART List	Price	Part No.	NAME OF PART	List Price
24060	APPENDIX TO BE ADDED TO PRESENT COMPONENT PARTS PRICE LIST: Barrel Assembly, ADX GRADE, 12 Ga. (30in.) VENT RIB only (includes Barrel, Barrel Guide Pin, Barrel Guide Ring, Front Sight (Ivory), Magazine Cap Detent, Magazine Cap De-)	25411 16992 23805 25385 16923	Butt Plate Screw, ADX-SX-TX GRADE	\$ ₁
24061 24062 25475 25476 25477 25478 23800 23802 24060 24061 25215 22971 25216 25288	tent Spring, Middle Sight, Ventilated Rib) Barrel Assembly, ADX GRADE, 12 Ga. (28 in.) VENT RIB only Barrel Assembly, ADX GRADE, 12 Ga. (26 in.) VENT RIB only Barrel Assembly, ADX GRADE, 16 Ga. (28 in.) VENT RIB only Barrel Assembly, ADX GRADE, 16 Ga. (26 in.) VENT RIB only Barrel Assembly, ADX GRADE, 20 Ga. (26 in.) VENT RIB only Barrel Assembly, ADX GRADE, 20 Ga. (26 in.) VENT RIB only Sorrel Assembly, ADX GRADE, 20 Ga. (26 in.) VENT RIB only Barrel Assembly, SX GRADE, 20 Ga. (26 in.) VENT RIB only SX GRADE, 12 Ga. (26 in.) only) VENT RIB only (includes same as SKEET GRADE) Barrel Assembly, SX GRADE, 20 Ga. (26 in. only) VENT RIB only Barrel Assembly, TX GRADE, 12 Ga. (30 in.) VENT RIB only (includes same as TRAP GRADE) Barrel Assembly, TX GRADE, 12 Ga. (28 in.) VENT RIB only Barrel Assembly, TX GRADE, 12 Ga. (28 in.) VENT RIB only Barrel Assembly, MAGNUM GRADE, 12 Ga. only (30 in. only) PLAIN (includes same as PLAIN Barrel) (3 in. chamber) Barrel Assembly, MAGNUM GRADE, 12 Ga. only (30 in.) VENT RIB (includes same as MAGNUM GRADE plus Ventilated Rib, Front Sight (Ivory), Middle Sight) (3 in. chamber) Barrel Assembly, RSS GRADE, 12 Ga. (26 in.) PLAIN (includes Barrel, Barrel Guide Pin, Barrel Guide Ring, Front Sight, Front Sight Ramp, Rear Sight Assembly, Rear Sight Base	Price on Application Application	22897 16917 16915 24525 16456 25585 22133 24375 16980 21386 16909 22991	Magazine Cap Assembly, MAGNUM GRADE	les les ret

PARTS AND PRICES SUBJECT TO CHANGE WITHOUT NOTICE

DELIVERIES ARE F.O.B. ILION, N. Y.

Send all guns for factory service and inquiries on service and parts to REMINGTON ARMS COMPANY, INC.

Arms Service Division

Ilion, New York 13357

All other inquiries are to be addressed to REMINGTON ARMS COMPANY, INC. Bridgeport, Connecticut 06602



Remington,

PRICE LIST



Autoloading Shotgun 3 SHOT

MODEL SPT-58


12-16-20 Gauge

When ordering parts — Model No., Part No. and Part Name must be given.

23045 F 23047 F 23690 F 23692 F 23692 F 189363 F 18673 F 18796 F 18796 F 18796 F 18797 C 16159 C 16159 C 18771 C	NOTE: Follower Latch, Follower Latch Pin, follower Latch Spring not used for 16 - 20 gauge model. ore-end, ADL GRADE, 12 Ga	1	18551 21385 16262 25115 23223 17514 17515 18750 17463 17518	Receiver Stud Recoil Pad (includes (2) screws) (Red) Recoil Pad Screw Safety Safety Safety Detent Ball Safety Spring Safety Spring Retaining Pin Sear Sear	
23045 F 23047 F 23690 F 23692 F 14256 F 19363 F 18673 F 18796 F 18796 F 18752 F 18752 F 18771 C 25385 C	gauge model. fore-end, ADL GRADE, 12 Ga. fore-end, SC GRADE, 12 Ga. fore-end, SC GRADE, 12 Ga. fore-end Ring fore-end Ring fore-end Ring Washer front Sight, (Vent Rib), Steel Bead front Sight (Vent Rib), Ivory Bead front Sight Retaining Pin (Vent Rib)	1	16262 25115 23223 17514 17515 18750 17463 17518	Recoil Pad Screw Safety Safety Detent Ball Safety Spring Safety Spring Retaining Pin Sear	
23045 F 23047 F 23690 F 23692 F 24256 F 19363 F 18673 F 18796 F 18796 F 18752 F 18752 F 18751 C	ore-end, ADL GRADE, 12 Ga. ore-end, ADL GRADE, 16 - 20 Ga. ore-end, SC GRADE, 12 Ga. ore-end, SC GRADE, 20 Ga. ore-end Ring ore-end Ring Washer oront Sight, (Vent Rib), Steel Bead oront Sight, (Vent Rib), Ivory Bead oront Sight Retaining Pin (Vent Rib)	1	25115 23223 17514 17515 18750 17463 17518	Safety Safety Detent Ball Safety Spring Safety Spring Retaining Pin Sear	
3047 F 3690 F 3692 F 4256 F 9363 F 8673 F 88796 F 88752 F 6159 G 8771 C 85385 C 8749 F	ore-end, ADL GRADE, 16 - 20 Ga. ore-end, SC GRADE, 12 Ga. ore-end, SC GRADE, 20 Ga. ore-end Ring ore-end Ring Washer orot Sight, (Vent Rib), Steel Bead oront Sight, (Vent Rib), Ivory Bead orott Sight Retaining Pin (Vent Rib)	1	23223 17514 17515 18750 17463 17518	Safety Detent Ball Safety Spring Safety Spring Retaining Pin Sear	
3690 F 3692 F 4256 F 9363 F 8673 F 8796 F 8918 F 8752 F 6159 G 8771 C 5385 C 8749 F	ore-end, SC GRADE, 12 Ga. ore-end, SC GRADE, 20 Ga. ore-end Ring ore-end Ring Washer cront Sight cront Sight, (Vent Rib), Steel Bead cront Sight, (Vent Rib), Ivory Bead cront Sight Retaining Pin (Vent Rib)		17514 17515 18750 17463 17518	Safety Spring Safety Spring Retaining Pin Sear	
3692 F 4256 F 9363 F 8673 F 8796 F 8918 F 8752 F 6159 G 8771 C 5385 C 8749 F	ore-end, SC GRADE, 20 Ga		17515 18750 17463 17518	Safety Spring Retaining PinSear	
4256 F 9363 F 8673 F 8796 F 8918 F 8752 F 6159 G 8771 C 5385 C 8749 F	ore-end Ring		18750 17463 17518	Sear	
4256 F 9363 F 8673 F 8796 F 8918 F 8752 F 6159 G 8771 C 5385 C 8749 F	ore-end Ring		17463 17518		
9363 F 8673 F 8796 F 8918 F 8752 F 6159 G 8771 C 5385 C 8749 F	Fore-end Ring Washer		17518	Sear Pin	
8673 F 8796 F 8918 F 8752 F 6159 G 8771 C 5385 C 8749 F	ront Sight				
8796 F 8918 F 8752 F 6159 G 8771 C 5385 C 8749 F	ront Sight, (Vent Rib), Steel Bead ront Sight, (Vent Rib), Ivory Bead ront Sight Retaining Pin (Vent Rib) Grip Cap			Sear Spring	
8918 F 8752 F 6159 G 8771 C 5385 C 8749 F	ront Sight, (Vent Rib), Ivory Bead ront Sight Retaining Pin (Vent Rib) Grip Cap	l	23085	Shell Latch, Left, 12 Ga. Use 16909	
8752 F 6159 G 8771 C 5385 C 8749 F	Front Sight Retaining Pin (Vent Rib)		20041	Shell Latch, Left, 16 Ga.	
6159 C 8771 C 5385 C 8749 F	Grip Cap	ŀ	20042	Shell Latch, Left, 20 Ga.	
8771 C 5385 C 8749 F		l	23080	Shell Latch, Right, 12 Ga.	
5385 C 8749 F		İ	20046	Shell Latch, Right, 16 Ga.	
8749 F	Grip Cap, TB GRADE	i	20047	Shell Latch, Right, 20 Ga.	
8749 F	Grip Cap Screw, TB GRADE		23560	Stock Assembly, ADL-SKEET GRADE, (includes	
	lammer			Stock, Butt Plate, Butt Plate Screw (2), Grip	
	lammer Pin			Cap), Use 22991	
	lammer Plunger		23785	Stock Assembly, BDL GRADE, includes same as	
	. 			ADL-SKEET GRADES). Use 21930	
	lammer Spring	·	22145	Stock Assembly, TB GRADE, (includes Stock,	
	ocking Block Assembly (oversize)	l		Grip Cap, Grip Cap Screw, Recoil Pad, Recoil	
22325 L	ocking Block Assembly, (includes Locking Block, Locking Block Stud)		21810	Pad Screw (2). Use 27441 Stock Assembly, SC GRADE, (includes same as	
9628 L	ocking Block Stud		10000	ADL-SKEET GRADES), Use 21812	
2895 A	Magazine Cap Assembly, 12 Ga. (includes		19993	Stock Bearing Plate	
	Magazine Cap, Magazine Cap Plunger, Magazine Cap Plunger Spring, Magazine	ŀ	18571	Stock Bolt	
	Magazine Cap Plunger Spring, Magazine	-	18572	Stock Bolt Lock Washer	
	Cap Selector, Magazine Cap Stud)	I	18573	Stock Bolt Washer	
3680 A	Magazine Cap Assembly, 16 Ga		25370	Trigger	
3681 A	Nagazine Cap Assembly, 20 Ga		20610	Trigger Assembly, (includes Trigger, Connector,	
7451 A	Aggazine Cap Detent	i	17533	Left; Connector, Right; Connector Pin) Trigger Pin	
	Magazine Cap Detent Spring		23665	Trigger Plate, R.H. Use 26235	
	Magazine Follower		23666	Trigger Plate, L.H. Use 26236	
	Magazine Spring	.	27300	Trigger Plate, L.H. Use 26236 Trigger Plate Assembly, R.H., 12 - 16 - 20 Ga.	
				(includes Carrier Assembly, Carrier Dog Fol-	
	Aagazine Spring Pin	ı		lower, Carrier Dog Follower Spring, Carrier	
	Middle Sight (white metal)	1		Latch, Carrier Latch Pin, Carrier Latch Spring,	
	Operating Handle	.		Carrier Pivot Tube, Disconnector, Hammer,	
3895 C	Operating Handle, D and F GRADE			Hammer Pin, Hammer Plunger, Hammer Spring, Safety, Safety Plunger, Safety Spring,	
5097 C	Operating Handle Plunger	1		Safety Spring Retaining Pin, Sear, Sear	
5098 C	Operating Handle Plunger Retainer			Safety Spring Retaining Pin, Sear, Sear Spring, Sear Pin, Trigger Assembly, Trigger	
6791 C	Operating Handle Spring			Pin, Trigger Plate, R.H.; Trigger Plate Pin Bushing, Trigger Plate Pin Detent Spring,	
	Piston Assembly, (includes Piston, Piston Liner,	į.		Bushing, Trigger Plate Pin Detent Spring,	
	Piston Ring)	- f	07005	Front; Trigger Plate Pin Detent Spring, Rear)	
6029 P	iston Ring	1	27305 17541	Trigger Plate Assembly, L.H. 12 - 16 - 20 Ga	
	Receiver Assembly, 12 Ga. (includes Receiver,	i	17539	Trigger Plate Pin BushingTrigger Plate Pin Detent Spring, Front	
2130 K	Ejector, Ejector Rivet (2), Follower Latch		17540	Trigger Plate Pin Detent Spring, Rear	
	Block, Follower Latch Block Pin, Magazine		20601	Trigger Plate Pin, Front	
	Tube Assembly)	i	20606	Trigger Plate Pin, Rear	
2131 R	Receiver Assembly, 16 Ga. (includes Receiver,			SUPERSEDED PARTS	
	Ejector, Ejector Rivet (2), Magazine Tube Assembly)	l			
0100 0		- 1	19659	Action Spring Stop	
2132 R	teceiver Assembly, 20 Ga. (includes same as	.	16918 16203	Action Spring Stop, MAGNUM GRADE	

INSTRUCTION FOLDER





NORMAL CLEANING AND CARE

can be done with these simple take-apart instructions

DISASSEMBLY

TO REMOVE BARREL AND FORE-END

CAUTION: Push safety "ON SAFE" (Red band will not show). Unscrew magazine cap. Slide barrel and fore-end together from gun.

TO REMOVE TRIGGER PLATE ASSEMBLY

Push out front and rear trigger plate pins. Lift trigger plate assembly from receiver. Inspect and clean, whenever necessary. Clean as a unit. NOTE: Do not allow cocked hammer to snap forward with trigger plate assembly removed from receiver.

TO REMOVE BREECH BOLT ASSEMBLY AND SLIDE

Remove piston mechanism. See opposite instructions. Pull out operating handle. Depress left shell latch in receiver. Pull action bar assembly with breech bolt assembly attached from front of receiver. Replace in reverse order.

FOR CLEANING

An evaporating cleaning solvent should be used. mechanisms remain clean much longer after shooting necessary precautions. Action britation is used.

RE-ASSEMBLY

TO REPLACE TRIGGER PLATE ASSEMBLY

Cock hammer and push safety to "ON SAFE" position. Slide trigger plate assembly in a receiver taking care that projecting parts of assembly clear receiver rails properly. At trigger plate pin holes and insert front and rear trigger plate pins.

TO REPLACE BARREL AND FORE-END

Hold both barrel and fore-end together with barrel guide ring fitted into top of fore-end. Place combined barrel and fore-end over magazine tube and slide towards receiver. Guide barrel extension into receiver and barrel guide ring over magazine tube. Open action to seat barrel properly into receiver. Replace magazine cap over barrel guide ring onto magazine tube and screw down tightly.

PLACE BARKEL AND FUKE-END

I both barrel and fore-end together with barrel guide ring fitted into top of fore-end. e combined barrel and fore-end over magazine tube and slide towards receiver. Guide el extension into receiver and barrel guide ring over magazine tube. Open action to barrel properly into receiver. Replace magazine cap over barrel guide ring onto lazine tube and screw down tightly.

may also require additional care.

BELOW FREEZING WEATHER

Special attention should be taken that all oil is removed from action parts. If a lubricant is desired — use dry graphite or similar non-congealing lubricant. Take care also to prevent rusting from condensation (cold weather to warm room temperature) on action parts.

Bing Walter and Autor va ... Cate Can Cate Can Cate Can Cate Cate Cate C LANGE SEE A SEC. A. Its table SECTIONAL VIEW THISTER PLATE PIN, REAR --- SHELL LATCH LEFT CAMBER BOG BH SHELL LATCH LEFT CAMBER BOG BH CAMBER STEEL CAMBER BH CAMBER STEEL CAMBER BOG BH CAMBER STEEL CAMBER BOG BH CAMBER STEEL CAMBER BH CAMBER BH CAMBER STEEL CAMBER BH CAMBER BH CAMBER STEEL CAMBER BH FOCKING BLOCK ASSEMBLY (LOCKING BLOCK STUD AMAGAZINE FOLLOWER MAGAZINE TURE ASSEMBLY RECEIVER FOLLOWER LATE! PLINIX FISTON 1111 PISTON ASSEMBLY FORE -END RING WASHE MAGAZINE CAF DETENT ACTION CLOSED

REPLACEMENT PARTS: Parts may be identified from the Sectional View.

Prices for parts will be furnished on application. When ordering parts, specify model, gauge, part name, and the serial number of the gun. All parts, including barrel assemblies, will be shipped as ordered but, since they are made to close dimensions, the particular part may require slight adjustment or fitting to assure proper functioning of the

Send all guns for factory service and inquiries on service and parts to

REMINGTON ARMS COMPANY, INC.
Arms Service Division
Ilion, New York

All other inquiries are to be addressed to REMINGTON ARMS COMPANY, INC.
Bridgeport, Connecticut

MORE POWER FOR HUNTERS

WITH REMINGTON AND PETERS STANDARD-LENGTH MAGNUM LOADS





Hunters who own 12, 16 or 20-gauge shotguns with standard 2¾" or longer chambers can now get denser, harder-hitting patterns with magnum power . . . in the sensational Remington "Express" and Peters "High Velocity" standard-length magnum loads. They're available in No. 2 and No. 4 shot in all three gauges. CAUTION: These magnum-powered shells should be used only in shotguns in good shooting condition and intended for maximum loads.

SIGHT ADJUSTMENT FOR "RIFLED SLUG SPECIAL"

WINDAGE — Rear sight eyepiece may be moved to left by turning windage screw clockwise. This will move slug impact to left. By turning screw counter clockwise rear sight eyepiece may be moved to right. This will move slug impact to right. NOTE: Windage screw is located beneath eyepiece.

ELEVATION OR RANGE

Rear sight may be raised or lowered by sliding notched sight step beneath eyepiece back and forth. Slug impact will lift, or range increase, by raising rear sight. Slug impact will lower, or range decrease, if rear sight is lowered.

"SPORTSMAN"—58, "EXPRESS,"
"HIGH VELOCITY," and "POWER-MATIC" are Reg. U.S. Pat.
Off., by Remington Arms Company, Inc., Bridgeport 2, Conn.
Form RD-5287 Rev. 1161 Litho in U.S.A.

Firearms Value & Reference Books

NOTE: We do not provide information on firearms' values. You may want to have your firearm appraised by a gunsmith. The following sources may also be helpful. We do not accept responsibility for the goods or services provided by these sources.

Firearms Value Books

Blue Book of Gun Values
Blue Book Publications
8009 34th Avenue South #175
Minneapolis, MN 55425
800-877-GUNS

Flayderman's Guide to Firearm Values
Gun List
Modern Gun Values
Krause Publications
700 East State Street
Iola, WI 54990-0001
847-573-8530

- raméty

Gun Trader's Guide
Stoeger Publishing Company
5 Mansard Court
Wayne, NJ 07470
973-872-9500

Reference Books

The Remington 700
John Flacy
Brownells, Inc.
200 South Front Stre

200 South Front Street Montezuma, IA 50171

515-623-5401

Shooter's Bible Stoeger Publishing Company 5 Mansard Court Wayne, NJ 07470 973-872-9500 Cartridges of the World Frank C. Barnes

Standard Catalog of Firearms

Krause Publications 700 East State Street Iola, WI 54990-0001 847-573-8530

Remington, America's Oldest

Gunmanker

Remington Arms Co.

PO Box 700

Madison, NC 27025 Attention: History Book

800-423-8495